

## Module F

### PRINCIPLES OF DISINFECTION AND STERILIZATION IN THE DENTAL SETTING

Statewide Program for Infection Control and Epidemiology (SPICE)

UNC School of Medicine

---

---

---

---

---

---

---

---

### OBJECTIVES

- Describe the principles of disinfection and sterilization
- Provide an overview of current methods for disinfection and sterilization
- Discuss training and quality control methods and required documentation

---

---

---

---

---



---

---

---

### PRINCIPLES

- Factors influencing the efficacy of disinfection and sterilization
  - How well the object is cleaned
  - Type and amount of material
  - Solution concentration
  - Exposure time
  - Design of object
  - Temperature and pH of disinfectant

---

---

---

---

---

---

---

---



---

---


---

---

---


---

## PRINCIPLES



BIOHAZARD

- Transport of contaminated items:
  - Must be contained. The type of container depends on the item being transported:
  - Puncture-resistant, leak-proof, closable containers must be used for devices with edges or points capable of penetrating container or skin
  - Must have a bio-hazard label or be red in color (never via gloved hands alone)
  - Items should be kept moist during transport by adding a towel moistened with water (not saline) or a foam, spray or gel product specifically intended for this use
  - Avoid transporting contaminated items in a liquid
- Reusable collection containers for holding contaminated items should be made of material that can be effectively decontaminated
- Use separate collection containers for contaminated versus re-processed or clean items



---

---

---

---

---

---


---


---

## CLEANING INSTRUMENTS

### MANUAL

- Medical equipment/devices **MUST** be pre-cleaned prior to high level disinfection or sterilization
- Contaminants such as dirt, blood or other body fluids, if present, can act as a barrier
- ALWAYS REMEMBER:
  - Do not use a high-level disinfection or sterilant solution to "hold" instrument
  - A fluid-resistant gown should be worn
  - Wear puncture-resistant heavy-duty utility gloves
  - Wear face protection (eyes and mouth) to protect against splashes





---

---

---

---

---

---

---

---

## CLEANING INSTRUMENTS

### AUTOMATED



**Automated cleaning equipment**

- Ultrasonic cleaner
- Instrument washer
- FDA regulated instrument washer

**Benefits:**

- Improve efficacy of cleaning process
- Reduce handling of sharp instruments
- Reduce risk of employee exposure

**Follow manufacturer's recommendations:**

- Dilution
- Temperature
- Water hardness
- Use

**After cleaning, rinse with water**



---

---

---

---

---

---

---

---

### KNOWLEDGE CHECK

Which of the following statements is true?

1. Manual cleaning of objects is safer than automated cleaning
- ✓ 2. Pre-cleaning is the most important factor in processing objects
3. Objects do not need to be pre-cleaned if they are going to be sterilized
4. Household dishwashers can be used for pre-cleaning of instruments.

---

---

---

---

---

---

---

---

### METHODS USED FOR DISINFECTION AND STERILIZATION




---

---

---

---

---

---

---

---

### SPAULDING CLASSIFICATION

**Spaulding Classification of Surfaces:**

- **Critical** – Objects which enter normally sterile tissue or the vascular system and require sterilization
- **Semi-critical** – Objects that contact mucous membranes or non-intact skin and require high-level disinfection, which kills all but high-levels of bacterial spores
- **Non-critical** – Objects that contact intact skin but not mucous membranes, and require low-level disinfection

---

---

---

---

---

---

---

---

## PROCESSING CRITICAL INSTRUMENTS

critical

- **Critical** Items:
  - Penetrate or enter normally sterile tissue or spaces, including the vascular system (Surgical instruments, cardiac catheters, IV devices, urinary catheters)
  - High risk of transmitting infection if handled improperly
  - Must be sterilized between uses or used as single-use disposable devices

*Goal: Sterility = devoid of all microbial life*

---

---

---

---

---

---

---

---

## METHODS

critical

- Four activities involved in the sterilization and disinfection of critical objects
  - Sterilization/Disinfection  
*(Steam, dry heat, liquid chemical)*
  - Monitoring
  - Packaging  
*(Wrapping, record keeping, loading)*
  - Storage

---

---

---

---

---

---

---

---

## STERILIZATION

critical

- Steam sterilization
- Hydrogen peroxide gas plasma
  - Ethylene oxide
  - Ozone
- Vaporized hydrogen peroxide
  - Steam formaldehyde

• = high temperature  
• = low temperature

---

---

---

---


---

---

---

---

## STEAM STERILIZATION



- Advantages
  - Non-toxic
  - Cycle easy to control and monitor
  - Inexpensive
  - Rapidly microbicidal
  - Rapid cycle time
  - Least affected by organic/inorganic soils
  - Penetrates medical packing, device lumens



---

---

---

---


---

---

---

---

## STEAM STERILIZATION



- Disadvantages
  - Deleterious for heat labile instruments
  - Inappropriate for heat-sensitive instruments
  - Inappropriate for moisture-sensitive instruments
    - Dulling
    - Rusting
  - Potential for burns



---

---

---

---

---

---

---

---

## STEAM STERILIZATION

- Steam under pressure (autoclaving)
  - Gravity displacement:
    - Exposure: 30 minutes
    - Temperature: 121°C
  - Pre-vacuum:
    - Exposure: 4 minutes
    - Temperature: 132°C




---

---

---

---

---


---


---

---

## DRY HEAT STERILIZATION

- Transfers heat energy from *air* inside the oven to the instruments
- Requires higher temperatures
- Good for items that are likely to dull or rust in the autoclave,
- Good for powders, cellulose and ink
- Packaging must be able to withstand high temperatures






---

---

---

---


---

---

---


---

## LIQUID CHEMICAL STERILANTS/DISINFECTANTS



**Liquid chemical sterilants/disinfectants**

- Only for heat-sensitive critical and semi-critical devices
- Exposure can be harmful to providers and patients
- Can not be stored
- Heat tolerant or disposable alternatives are available




---

---

---

---

---

---

---

---

critical

## STERILIZATION REVIEW



- Steam is preferred for critical items not damaged by heat
- Follow the operating parameters recommended by the manufacturer
- Use low temperature sterilization technologies for reprocessing critical items damaged by heat
- Items immersed in chemo-sterilizer solutions should be used immediately




---

---

---

---

---

---

---

---

### KNOWLEDGE CHECK

Patient care equipment and devices should be disinfected/sterilized based on:

1. Items intended use
2. What the item is going to come in contact with (mucous membranes or non-intact skin) a. 1 and 4
3. The number of patients you have scheduled for the day b. 2 and 4
4. What the physician tells you to do. c. 1 and 2 d. 3 and 4




---

---

---

---

---

---

---

---

### MONITORING



- The Joint Commission (TJC)
- Centers for Medicare and Medicaid Services (CMS)
- 10A NCAC 41.0206 (NC Rule .0206)

---

---

---

---

---

---

---

---

### STERILIZATION MONITORING



Sterilization monitored routinely by combination of physical, chemical, and biological parameters




---

---

---

---

---

---



---

---

## STERILIZATION MONITORING

*Physical - cycle time, temperature, pressure*

- Assessment of:
  - Time
  - Temperature
  - Pressure via gauge
- Documentation:
  - Maintain monitor log
  - Computer readout


---

---

---

---

---


---

---


---

## STERILIZATION MONITORING

*Chemical - heat or chemical sensitive inks that change color when germicidal-related parameters reached*



- Internal Chemical Indicator
  - Validates the sterilant penetrated the pack or tray
  - Advantage of the pack control monitor is that it is inside each pack in multiple locations
  - Detect local problem




---

---

---

---

---

---

---

---



## STERILIZATION MONITORS

*Biological - Bacillus spores that directly measure sterilization*

Steam - *Geobacillus stearothermophilus*

Dry heat - *B. atrophaeus* (formerly *B. subtilis*)

Ethylene oxide (ETO) - *B. atrophaeus*


---

---

---

---

---

---

---

---

## MONITORING REVIEW

- Monitor each load with physical and chemical (internal and external) indicators.
- Use biological indicators to monitor effectiveness of sterilizers at least weekly with spores intended for the type of sterilizer.
- Use biological indicators for every load containing implantable items
- Policy for management of positive BI indicator

SPICE

---

---

---

---

---

---

---

---

## MONITORING OF STERILIZERS

**Following a single positive biological indicator from steam sterilization:**

- Remove the sterilizer from service and review sterilizer instructions
- Retest the sterilizer
- If spore test negative, put the sterilizer back in service
- If the spore test is positive: do not use until it has been inspected; and recall (to the extent possible) all items processed since the last negative spore test; challenge in three consecutive empty sterilization cycles.

Single positive biological indicator (BI) from other than steam sterilization: treat as non-sterile all items back to last load tested with negative indicator

SPICE

---

---

---

---


---

---

---

---

## Record-Keeping



Maintain sterilization records (physical, chemical and biological)

For each sterilization cycle record"

- the type of sterilizer and cycle used;
- the load identification number;
- the load contents,
- the exposure parameters (time and temperature);
- the operator's name or initials; and
- the results of physical, chemical, and biological monitoring.

SPICE

---

---

---

---

---

---

---

---

## PACKAGING



Video Clip: To start the video click on the image.





---

---

---

---

---


---

---

---

## PACKAGING

- Once cleaned, dried and inspected items, requiring sterilization must be:
  - Wrapped or place in rigid containers
  - Arranged in trays or baskets per Association of Medical Instrumentation (AAMI) guidelines (hinged instruments should be opened for example)
- Follow manufacturer's instructions for preparation
- Wrapping done to prevent gaps and tenting
- Wrapping material must:
  - Allow penetration of sterilant, be compatible with sterilizer, be puncture resistant, durable and have FDA clearance
- Choices in wrapping products include:
  - Peel packs, rigid containers, roll stock (self seal) and woven or nonwoven sterile wraps



---

---

---

---


---

---



---


---

## LOADING



- Place items/packages correctly and loosely into the sterilizer so as not to impede penetration of the sterilant
- Peel packs and non-perforated containers should be placed on their edge
- Peel packs:
  - Be used, filled and opened according to the pouch manufacturer's instructions
  - Be of a size and strength to accommodate the item being packaged
  - Be closed so that all pouch seals are smooth (i.e., without folds, bubbles or wrinkles)
  - Be written only on the non-porous side of the pouch



---

---

---

---

---

---

---

---

## SUMMARY METHODS

- Steam is preferred for critical (and semi-critical) items not damaged by heat
- Always follow manufacturer's operating instructions
- Use an "FDA cleared" container, wrapping or packaging system that is compatible with the type of sterilization process used
- Do not overload the chamber

---

---

---

---

---


---

---

---

## STORAGE OF STERILE ITEMS

- Ensure the sterile storage area is a well-ventilated area that provides protection against dust, moisture, and temperature and humidity extremes.
- Sterile items should be stored so that packaging is not compromised.
- Label sterilized items with a load number that indicates the sterilizer used, the cycle or load number, the date of sterilization, and if applicable the expiration date.




---

---

---

---

---

---

---

---

## STORAGE OF STERILE ITEMS

- **Event-related** shelf life recognizes that the product remains sterile until an event causes it to become contaminated (e.g. moisture).
- Packages should be evaluated before use for loss of integrity. Repack and reprocess if compromised.
- If **time related** storage of sterile items is used, label the pack at the time of sterilization with an expiration date. Once this date expires, reprocess the pack.

---

---

---

---

---


---

---


---

## STORAGE

### GENERAL GUIDELINES



- All patient care items must be stored at least 8" off the floor
- Open rack storage should have a bottom shelf (plexi-glass for example)
- Stored at least 18" below the ceiling or the sprinkler head (according to fire code)
- Stored at least 2" inches from outside wall
- Items should be stored in areas of limited traffic
- Stored in an area with controlled temperature and humidity
- Outside shipping containers and corrugated cartons should not be used as storage containers
- Items should not be stored under sinks or exposed water/sewer pipes
- Windowsills should be avoided
- Closed or covered cabinets are preferred



---

---

---

---


---

---

---


---

## SPAULDING CLASSIFICATION



**Spaulding Classification of Surfaces:**

- **Critical** – Objects which enter normally sterile tissue or the vascular system and require sterilization
- **Semi-critical** – **Objects that contact mucous membranes or non-intact skin and require high-level disinfection, which kills all but high-levels of bacterial spores**
- **Non-critical** – Objects that contact intact skin but not mucous membranes, and require low-level disinfection



---

---

---

---

---

---

---

---

## SEMI-CRITICAL INSTRUMENTS



- Examples of **Semi-Critical** Items:
  - Mouth Mirrors
  - Cheek retractors
  - Handpieces\*
  - Reusable dental impression trays
  - Amalgam condensers



*\*Although dental handpieces are "by definition" considered a semi-critical item, they should always be heat-sterilized between uses*



---

---

---

---

---

---

---

---

## HIGH-LEVEL DISINFECTANTS

Semi-critical

Germicide	Concentration
Glutaraldehyde (Cidex)	≥ 2.0%
Ortho-phthalaldehyde (Cidex OPA)	0.55%
Hydrogen Peroxide* (Sporox)	7.5%
Hydrogen Peroxide and peracetic acid* (Peract)	1.0% / 0.08%
Hydrogen Peroxide and peracetic acid* (Endospore +)	7.5% / 0.23%
Hypochlorite (free chlorine)* (Sterilox ©)	650-675 ppm
Accelerated hydrogen peroxide (Resert XL)	2.0%
Peracetic Acid (Steris 20)	0.2%
Glutaraldehyde and Isopropanol (Aldahol III)	3.4% / 26%
Glutaraldehyde and phenol/phenate (Sporicidin)	1.21% / 1.93%

SPICE

---

---

---

---

---

---

---

---

## PROCESSING SEMI-CRITICAL INSTRUMENTS

Semi-critical

### Methods for processing:

A common method of high level disinfection is immersion in either Glutaraldehyde (Cidex®) or Ortho-phthalaldehyde (Cidex OPA®)



SPICE

---

---

---

---

---

---

---

---

Manufacturer's instructions for dilution and quality control testing must be followed. Must use correct test strip for solution!

Semi-critical

- Submerge the test strip into the solution prior to each use to monitor minimum effective concentration (MEC)
- Remove excess by standing upright on paper towel
- Read results according to manufacturer's instructions (*recommended time period and change in color of the test strip*)
- Document findings



SPICE

---

---

---

---

---


---

---

---

## SPAULDING CLASSIFICATION

### Spaulding Classification of Surfaces:

- 
- **Critical** – Objects which enter normally sterile tissue or the vascular system and require sterilization
  - **Semi-critical** – Objects that contact mucous membranes or non-intact skin and require high-level disinfection, which kills all but high-levels of bacterial spores
  - **Non-critical** – Objects that contact intact skin but not mucous membranes, and require low-level disinfection




---

---

---

---

---


---

---

---

## ROLE OF THE ENVIRONMENT

Non-critical




---

---

---

---

---

---

---

---

## LIQUID DISINFECTANTS

Non-critical

Disinfectant Agent	Use Concentration
Ethyl or isopropyl alcohol	70% - 90%
Chlorine (bleach)	100 ppm
Phenolic	UD
Iodophor	UD
Quaternary ammonium compound (QUAT)	UD
Improved/Accelerated hydrogen peroxide	0.5%, 1.4%




---

---

---

---

---

---

---



---

### PROPERTIES OF AN IDEAL DISINFECTANT

- Broad Spectrum
- Fast Acting
- Non Toxic
- Surface Compatibility

- Easy to Use
- Acceptable odor
- Economical

Non-critical

---

---

---

---


---

---

---



---

### OTHER ENVIRONMENTAL ISSUES



#### Blood and Body Fluid Spills

- Promptly clean and decontaminate
- Use appropriate PPE
- Clean spills with dilute bleach solution (1:10 or 1:100) or an EPA-registered hospital disinfectant with a TB or HIV/HBV kill claim.

---

---

---

---

---

---

---

---

### KNOWLEDGE CHECK

Contaminated reusable items should be:

1. Handled as little as possible
2. Placed in a bio-hazard labeled container and left in room until end of work day
3. Pre-cleaned in sink in the exam room
4. Transported immediately after use and not left in the patient care area


Select correct one

a. 1 and 3

b. 3 and 4

✓ c. 1 and 4

d. 1, 2, 3, 4



---

---

---

---

---

---

---

---

## TRAINING AND QUALITY CONTROL



- Provide comprehensive and intensive training for all staff assigned to reprocess medical/surgical instruments
- To achieve and maintain competency:
  - Staff receive hands-on training
  - Work with supervision until competency is documented
  - Competency testing should be conducted at commencement of employment and no less than annually
  - Training and competencies should be documented




---

---

---

---

---

---

---

---

## ADDITIONAL RESOURCES



[www.aami.org](http://www.aami.org)

**CDC Guidelines for Disinfection and Sterilization in Healthcare Facilities**

<https://www.cdc.gov/infectioncontrol/pdf/guidelines/disinfection-guidelines.pdf>

**Guidelines for Infection Control in Dental Health-Care Settings — 2003**

<https://www.cdc.gov/mmwr/PDF/rr/rr5217.pdf>

**Summary of Infection Prevention Practices in Dental Settings; Basic Expectations of Care**

<https://www.cdc.gov/oralhealth/infectioncontrol/pdf/safe-are2.pdf>




---

---

---

---

---

---

---

---

## QUESTIONS?




---

---

---

---

---

---

---

---