



Slide 1




Slide 2



Slide 3



Slide 4



Slide 5

F Principles of Disinfection and Sterilization

Principles

Decontamination

Packaging

Sterilize

Packaging area

- Inspecting
- Assembling
- Packaging

Sterilization/storage area

- Sterilizers/supplies
- Incubators
- Enclosed storage

Slide 6

F Principles of Disinfection and Sterilization

Principles

Management of reusable contaminated items:

- Handle as little as possible
- Use appropriate PPE
- Remove gross soil or debris at the point of use (gauze sponge moistened with water/disinfectant wipe for example)
- Immediately contain and transport to the decontamination area or soiled utility room where cleaning procedures can be accomplished away from patient care


Slide 7

F Principles of Disinfection and Sterilization

Principles

Transport of contaminated items:

- Must be contained. The type of container depends on the item being transported:
 - Puncture-resistant, leak-proof, closable containers must be used for devices with edges or points capable of penetrating container or skin
 - Must have a bio-hazard label or be red in color (never via gloved hands alone)
- Items should be kept moist during transport by adding a towel moistened with water (not saline) or a foam, spray or gel product specifically intended for this use
- Avoid transporting contaminated items in a liquid
- Reusable collection containers for holding contaminated items should be made of material that can be effectively decontaminated
- Use separate collection containers for contaminated versus re-processed or clean items








Slide 8

F Principles of Disinfection and Sterilization

Principles

Factors influencing the efficacy of disinfection and sterilization

- How well the object is cleaned/type and amount of material
- Testing of the disinfectant
 - Solution concentration
 - Exposure time
- Design of object
- Temperature and pH of disinfectant





Slide 9

F Principles of Disinfection and Sterilization

Cleaning Instruments - *Manual*

- Medical equipment/devices **MUST** be pre-cleaned prior to high level disinfection or sterilization.
- Contaminants such as dirt, blood or other body fluids, if present, can act as a barrier.
- If manual cleaning is performed:
 - Use work practice controls to reduce the chance of injury from sharp objects
 - Never reach into trays or container holding sharp instruments that cannot be seen
 - Use a long-handled brush to keep the scrubbing hand away from sharp instruments
 - Wear puncture-resistant, heavy-duty gloves

After cleaning, instruments should be rinsed with water to remove chemical detergent residue.



Slide 10

F Principles of Disinfection and Sterilization

Cleaning Instruments - *Automated*



Automated cleaning equipment
Ultrasonic cleaner
Instrument washer
FDA regulated instrument washer

Benefits:

- Improve efficacy of cleaning process
- Reduce handling of sharp instruments
- Reduce risk of employee exposure

Follow manufacturer's recommendations:

- Dilution
- Temperature
- Water hardness
- Use

After cleaning, rinse with water




Slide 11

F Principles of Disinfection and Sterilization

Knowledge Check

Which of the following statements is true?

- A. Manual cleaning of objects is safer than automated cleaning
- ✓ B. Pre-cleaning is the most important factor in reprocessing objects
- C. Objects do not need to be pre-cleaned if they are going to be sterilized
- D. Household dishwashers can be used for pre-cleaning of instruments.



Slide 12

F Principles of Disinfection and Sterilization

Methods Used for Disinfection and Sterilization



Slide 13


F Principles of Disinfection and Sterilization

Spaulding Classification

Spaulding Classification of Surfaces:

- Critical** – Objects which enter normally sterile tissue or the vascular system and require sterilization
- Semi-critical** – Objects that contact mucous membranes or non-intact skin and require high-level disinfection, which kills all but high-levels of bacterial spores
- Non-critical** – Objects that contact intact skin but not mucous membranes, and require low-level disinfection

Spaulding Classification



Slide 14


F Principles of Disinfection and Sterilization

Processing Critical Instruments

Critical Items:

- Penetrate or enter normally sterile tissue or spaces, including the vascular system (Surgical instruments, cardiac catheters, IV devices, urinary catheters)
- High risk of transmitting infection if handled improperly
- Must be sterilized between uses or used as single-use disposable devices

Goal: Sterility = devoid of all microbial life






Slide 15

F Principles of Disinfection and Sterilization

Processing Critical Instruments

Four activities involved in the sterilization and disinfection of critical objects

- Sterilization/Disinfection
(Steam, dry heat, liquid chemical)
- Monitoring
- Packaging
(Wrapping, record keeping, loading)
- Storage






Slide 16

F Principles of Disinfection and Sterilization

Sterilization

- Steam sterilization (most common in dental setting)
- Hydrogen peroxide gas plasma
 - Ethylene oxide
 - Ozone
- Vaporized hydrogen peroxide
 - Steam formaldehyde

• high temperature
• low temperature



Slide 17

F Principles of Disinfection and Sterilization

Steam Sterilization



Advantages


- Non-toxic
- Cycle easy to control and monitor
- Inexpensive
- Rapidly microbicidal
- Rapid cycle time
- Least affected by organic/inorganic soils
- Penetrates medical packing, device lumens

SPICE
Society for Professional Infection Control and Epidemiology

Slide 18

F Principles of Disinfection and Sterilization

Steam Sterilization



Disadvantages

- Deleterious for heat labile instruments
- Inappropriate for heat-sensitive instruments
- Inappropriate for moisture-sensitive instruments
- Dulling
- Rusting
- Potential for burns

SPICE
Society for Professional Infection Control and Epidemiology

Slide 19

F Principles of Disinfection and Sterilization

Steam Sterilization

2 types of steam sterilization

Steam under pressure (autoclaving)

- Gravity displacement:
 - Exposure: 30 minutes
 - Temperature: 121oC
- Pre-vacuum:
 - Exposure: 4 minutes
 - Temperature: 132oC



SPICE
SCHOOL OF PUBLIC HEALTH
UNIVERSITY OF NORTH CAROLINA AT CHAPEL HILL

Slide 20


F Principles of Disinfection and Sterilization

Steam Sterilization

2 types of steam sterilization

Steam under pressure (autoclaving)

- Gravity displacement:
 - Exposure: 30 minutes
 - Temperature: 121oC
- Pre-vacuum:
 - Exposure: 4 minutes
 - Temperature: 132oC



SPICE
SCHOOL OF PUBLIC HEALTH
UNIVERSITY OF NORTH CAROLINA AT CHAPEL HILL


Slide 21

F Principles of Disinfection and Sterilization

Steam Sterilization

Steam under pressure (autoclaving) 2 types of steam sterilization

- Gravity displacement:
 - Exposure: 30 minutes
 - Temperature: 121oC
- Pre-vacuum:
 - Exposure: 4 minutes
 - Temperature: 132oC



SPICE
SCHOOL OF PUBLIC HEALTH
UNIVERSITY OF NORTH CAROLINA AT CHAPEL HILL

Slide 22

F Principles of Disinfection and Sterilization

Dry Heat Sterilization

- Transfers heat energy from air inside the oven to the instruments
- Requires higher temperatures
- Good for items that are likely to dull or rust in the autoclave,
- Good for powders, cellulose and ink
- Packaging must be able to withstand high temperatures



SPICE
SCHOOL OF PUBLIC HEALTH
UNIVERSITY OF NORTH CAROLINA AT CHAPEL HILL

Slide 23

F Principles of Disinfection and Sterilization

Liquid Chemical Sterilants/Disinfectants



- Only for heat-sensitive critical and semi-critical devices
- Exposure can be harmful to providers and patients
- Can not be stored
- Heat tolerant or disposable alternatives are available

Sterilization




Slide 24

F Principles of Disinfection and Sterilization

Sterilization Review

- Steam is preferred for critical items not damaged by heat
- Follow the operating parameters recommended by the manufacturer
- Use low temperature sterilization technologies for reprocessing critical items damaged by heat
- Items immersed in chemo-sterilizer solutions should be used immediately

Sterilization



Slide 25

F Principles of Disinfection and Sterilization


Knowledge Check

Patient care equipment and devices should be disinfected/sterilized based on:

1. Items intended use
2. What the item is going to come in contact with
3. The number of patients you have scheduled for the day
4. What the dental provider tells you to do

Choose


- A. 1 and 4
- B. 2 and 4
- C. 1 and 2
- D. 3 and 4




Slide 26

F Principles of Disinfection and Sterilization

Monitoring



- Centers for Medicare and Medicaid Services (CMS)
- 10A NCAC 41.0206 (NC Rule .0206)
- The Joint Commission (TJC)







Slide 27

F Principles of Disinfection and Sterilization

Sterilization Monitoring

Sterilization monitored routinely by combination of physical, chemical, and biological parameters

- Physical - cycle time, temperature, pressure
- Chemical - heat or chemical sensitive inks that change color when germicidal-related parameters reached
- Biological - Bacillus spores that directly measure sterilization







Slide 28

F Principles of Disinfection and Sterilization

Sterilization Monitoring

Sterilization monitored routinely by combination of physical, chemical, and biological parameters


- Physical - cycle time, temperature, pressure
- Chemical - heat or chemical sensitive inks that change color when germicidal-related parameters reached
- Biological - Bacillus spores that directly measure sterilization



Slide 29

F Principles of Disinfection and Sterilization

Monitoring Of Sterilizers



Internal Chemical Indicator

- Validates the sterilant penetrated the pack or tray
- Advantage of the pack control monitor is that it is inside each pack in multiple locations
- Detect local problem

SPICE
Statewide Program for Infection Control and Epidemiology


Slide 30

F Principles of Disinfection and Sterilization

Monitoring Of Sterilizers

Biological Monitors

- Steam
Geobacillus stearothermophilus
- Dry heat
B. atrophaeus (formerly *B. subtilis*)
- Ethylene oxide (ETO)
B. atrophaeus





SPICE
Statewide Program for Infection Control and Epidemiology

Slide 31


F Principles of Disinfection and Sterilization

Monitoring of Sterilizers

IF biological indicator is positive (after sterilization cycle)



Follow CDC and AORN procedures



Slide 32

F Principles of Disinfection and Sterilization

Monitoring of Sterilizers

Steam sterilization



- Remove



After single  

- Retest
- Recall implantable items



Next test 

- Return to service



Slide 33

F Principles of Disinfection and Sterilization

Monitoring of Sterilizers

Steam sterilization

Next test 

• Do not use until inspected 
• Run 3X
• Reprocess

• Recall items if still positive
• Defective procedures possible




Slide 34

F Principles of Disinfection and Sterilization

Monitoring of Sterilizers

Steam sterilization

If patient care items were used before retrieval, the infection preventionist should assess the risk of infection in collaboration with the physician, and if needed, consult an outside reprocessing specialist.

If item was used  → Assess risk 




Slide 35

F Principles of Disinfection and Sterilization

Monitoring of Sterilizers

Steam sterilization

There is a minimal risk associated with items in a load that show spore growth, especially if the item was properly cleaned and the time, temperature and pressure was achieved (as demonstrated by a chemical indicator and monitoring documentation).



Slide 36

F Principles of Disinfection and Sterilization

Monitoring of Sterilizers

Other Sterilization Methods

After single  

- Treat as non-sterile all items that have been processed in that sterilizer, dating from the last sterilization cycle in which there was a negative biological indicator.
- Retrieve the items and reprocess.




Slide 37

F Principles of Disinfection and Sterilization

Monitoring Review

- Monitor each load with physical and chemical (internal and external) indicators.
- Use biological indicators to monitor effectiveness of sterilizers at least weekly with spores intended for the type of sterilizer.
- Use biological indicators for every load containing implantable items
- Policy for management of positive BI indicator




Slide 38

F Principles of Disinfection and Sterilization


Record-Keeping

Maintain sterilization records (physical, chemical and biological) for each sterilization cycle record


- the type of sterilizer and cycle used
- the load identification number
- the load contents
- the exposure parameters (time and temperature)
- the operator's name or initials
- the results of physical, chemical, and biological monitoring



Slide 39



Slide 40




Slide 41


F Principles of Disinfection and Sterilization

Loading

- Place items/packages correctly and loosely into the sterilizer so as not to impede penetration of the sterilant
- Peel packs and non-perforated containers should be placed on their edge
- Peel packs:
 - Be used, filled and opened according to the pouch manufacturer's instructions
 - Be of a size and strength to accommodate the item being packaged
 - Be closed so that all pouch seals are smooth (i.e., without folds, bubbles or wrinkles)
 - Be written only on the non-porous side of the pouch



Consult manufacturer's recommendations







Slide 42

F Principles of Disinfection and Sterilization

Summary Methods

- Steam is preferred for critical (and semi-critical) items not damaged by heat
- Always follow manufacturer's operating instructions
- Use an "FDA cleared" container, wrapping or packaging system that is compatible with the type of sterilization process used
- Do not overload the chamber



Slide 43


F Principles of Disinfection and Sterilization

Storage Of Sterile Items


Ensure the sterile storage area is a well-ventilated area that provides protection against dust, moisture, and temperature and humidity extremes.

Sterile items should be stored so that packaging is not compromised.

Label sterilized items with a load number that indicates the sterilizer used, the cycle or load number, the date of sterilization, and if applicable the expiration date.



Storage





Slide 44


F Principles of Disinfection and Sterilization

Storage Of Sterile Items

Shelf life =



Storage



Slide 45


F Principles of Disinfection and Sterilization

Storage Of Sterile Items

Shelf life =

- **Event-related** shelf life recognizes that the product remains sterile until an event causes it to become contaminated (e.g. moisture).
- Packages should be evaluated before use for loss of integrity. Repack and reprocess if compromised.
- If **time related** storage of sterile items is used, label the pack at the time of sterilization with an expiration date. Once this date expires, reprocess the pack.

Storage




Slide 46

F Principles of Disinfection and Sterilization

General Guidelines

- All patient care items must be stored at least 8" off the floor
- Open rack storage should have a bottom shelf (plexi-glass for example)
- Stored at least 18" below the ceiling or the sprinkler head (according to fire code)
- Stored at least 2" inches from outside wall
- Items should be stored in areas of limited traffic
- Stored in an area with controlled temperature and humidity
- Outside shipping containers and corrugated cartons should not be used as storage containers
- Items should not be stored under sinks or exposed water/sewer pipes
- Windowsills should be avoided
- Closed or covered cabinets are preferred

Storage



Slide 47


F Principles of Disinfection and Sterilization

Spaulding Classification

Spaulding Classification of Surfaces:

- Critical** – Objects which enter normally sterile tissue or the vascular system and require sterilization
- Semi-critical** – Objects that contact mucous membranes or non-intact skin and require high-level disinfection, which kills all but high-levels of bacterial spores
- Non-critical** – Objects that contact intact skin but not mucous membranes, and require low-level disinfection

Semi-critical



Slide 48


F Principles of Disinfection and Sterilization

Semi-critical Instruments

Semi-Critical Items:

- Contact mucous membranes or non-intact skin (mouth mirrors, cheek retractors, **hand pieces**, reusable dental impression trays and amalgam condensers)
- Risk of transmitting infection if handled improperly
- CDC notes because most semi critical items used in dentistry are heat-tolerant, they also should be sterilized by using heat
- If heat sensitive item should at a minimum be processed using high-level disinfection or used as single-use disposable devices

Semi-critical Goal: High-level disinfection = free of all microorganisms except high numbers of bacterial spores



Slide 49

F Principles of Disinfection and Sterilization


Semi-critical Instruments

- **Semi-Critical** Items:
 - hand pieces*

*Although dental handpieces are "by definition" considered a semi-critical item, they should always be heat-sterilized between uses



semi-critical



Slide 50


F Principles of Disinfection and Sterilization

High-level Disinfectants

| Germicide | Concentration |
|---|---------------|
| Glutaraldehyde (Cidex) | ≥ 2.0% |
| Ortho-phthalaldehyde (Cidex OPA) | 0.55% |
| Hydrogen Peroxide* (Sporox) | 7.5% |
| Hydrogen Peroxide and peracetic acid* (Peract) | 1.0% / 0.08% |
| Hydrogen Peroxide and peracetic acid* (Endospore +) | 7.5% / 0.23% |
| Hypochlorite (free chlorine)* (Sterilox 0) | 650-675 ppm |
| Accelerated hydrogen peroxide (Resert XL) | 2.0% |
| Peracetic Acid (Steris 20) | 0.2% |
| Glutaraldehyde and Isopropanol (Aldahol III) | 3.4% / 26% |
| Glutaraldehyde and phenol/phenolate (Sporicidin) | 1.21% / 1.93% |

Exposure time: 38-45 min (US) and temperature: 20-25°C.
*May cause cosmetic and functional damage.

high-level




Slide 51

F Principles of Disinfection and Sterilization

Processing Semi-critical Instruments

Manufacturer's instructions for dilution and quality control testing must be followed.

- Submerge the test strip into the solution prior to each use to monitor minimum effective concentration (MEC)
- Remove excess by standing upright on paper towel
- Read results according to manufacturer's instructions (recommended time period and change in color of the test strip)
- Document findings



Must use correct test strip for solution!

SDICE
SOUTH CAROLINA
DENTAL INFECTION CONTROL AND EPIDEMIOLOGY


Slide 52

F Principles of Disinfection and Sterilization

Spaulding Classification

Spaulding Classification of Surfaces:

- Critical – Objects which enter normally sterile tissue or the vascular system and require sterilization
- Semi-critical – Objects that contact mucous membranes or non-intact skin and require high-level disinfection, which kills all but high-levels of bacterial spores
- Non-critical – Objects that contact intact skin but not mucous membranes, and require low-level disinfection



Non-critical

SDICE
SOUTH CAROLINA
DENTAL INFECTION CONTROL AND EPIDEMIOLOGY


Slide 53

F Principles of Disinfection and Sterilization

Non-critical Instruments

- **Non-Critical** Items:
 - Objects that contact intact skin but not mucous membranes (BP cuffs, counter tops, exam chairs)
 - Minimal risk of transmitting infection if handled improperly
 - Must be low-level disinfected on a routine basis


Non-critical



Slide 54

F Principles of Disinfection and Sterilization


Role of the Environment



| Pathogen | Survival Time |
|-----------------------|-------------------|
| MSSA | 7 days - 1 month |
| Acinetobacter | 3 days - 6 months |
| C. difficile (spores) | 6 months |
| VRE | 5 days - 6 months |
| Herpesvirus | 12 - 24 days |
| HBV | 7 days |
| HCV | 6 hours - 8 days |
| HIV | minutes - hours |

Survival of Pathogens

Non-critical




Slide 55

F Principles of Disinfection and Sterilization

Liquid Disinfectants

| Disinfectant Agent | Use Concentration |
|--|-------------------|
| Ethyl or isopropyl alcohol | 70% - 90% |
| Chlorine (bleach) | 100 ppm |
| Phenolic | UD |
| Iodophor | UD |
| Quaternary ammonium compound (QUAT) | UD |
| Improved/Accelerated hydrogen peroxide | 0.5%, 1.4% |

Non-critical
UD = Manufacturer's recommended use dilution



Slide 56

F Principles of Disinfection and Sterilization

L Properties of an Ideal Disinfectant

- Broad Spectrum
- Fast Acting
- Non-Toxic
- Surface Compatibility
- Easy to Use
- Acceptable odor
- Economical



Non-critical



Slide 57

F Principles of Disinfection and Sterilization

Other Environmental Issues OSHA



Use appropriate PPE

SPICE
SOUTH CAROLINA
PROGRAM FOR INFECTION CONTROL AND EPIDEMIOLOGY

Slide 58

F Principles of Disinfection and Sterilization

Other Environmental Issues OSHA

Blood and Body Fluid Spills

- Contaminated work surfaces shall be decontaminated with an appropriate disinfectant
 - After completion of procedures
 - Immediately or as soon as feasible when surfaces are overtly contaminated
 - After any spill of blood or other potentially infectious materials
 - At the end of the work shift if the surface may have become contaminated since the last cleaning
- When there are large spills of blood and/or body fluids it is important to clean or remove the spill prior to disinfecting the area
 - The first step is to clean and decontaminate the area promptly.
 - If the spill contains large amounts of blood or body fluids, clean the visible matter with disposable absorbent material, and discard the contaminated materials in appropriate, labeled container (treat as OSHA regulated medical waste).
 - Use EPA-registered disinfectants labeled tuberculocidal or EPA registered germicides with specific label claims for HIV or hepatitis B virus (HBV) in accordance with label instructions to decontaminate spills of blood and other body fluids

Use appropriate PPE

SPICE
SOUTH CAROLINA
PROGRAM FOR INFECTION CONTROL AND EPIDEMIOLOGY

Slide 59

F Principles of Disinfection and Sterilization


Knowledge Check

Contaminated reusable items should be:

1. Handled as little as possible
2. Placed in a bio-hazard labeled container and left in room until end of the workday
3. Pre-cleaned in sink in the exam room
4. Transported immediately after use and not left in the patient care area

Choose

- A. 1 and 3
- B. 3 and 4
- C. 1 and 4
- D. 1, 2, 3, 4



Slide 60



F Principles of Disinfection and Sterilization

Training and Quality Control

Provide comprehensive and intensive training for all staff assigned to reprocess medical/surgical instruments

To achieve and maintain competency:

- Staff receive hands-on training
- Work with supervision until competency is documented
- Competency testing should be conducted at commencement of employment and no less than annually
- Training and competencies should be documented




Slide 61

F Principles of Disinfection and Sterilization

Training and Quality Control

- Conduct monitoring/observations of process measures such as hand hygiene, use of PPE, environmental cleaning and disinfection/sterilization
- Ensure all products used for disinfection and/or sterilization have been approved by infection prevention
- Follow manufacturer instructions for use (IFUs) for preparation and packing of items



Slide 62


F Principles of Disinfection and Sterilization

Additional Resources

Guideline for Disinfection and Sterilization in Healthcare Facilities, 2008
William A. Rutala, Ph.D., M.P.H.^{1,2}, David J. Weber, M.D., M.P.H.^{1,2}, and the Healthcare Infection Control Practices Advisory Committee (HICPAC)
<https://www.cdc.gov/infectioncontrol/pdf/guidelines/disinfection-guidelines.pdf>

Summary of Infectious Prevention Practices in Dental Settings
Public Expectations for Oral Care
<https://www.cdc.gov/oralhealth/infectioncontrol/pdf/inf-ane2.pdf>

MMWR
Morbidity and Mortality Weekly Report
Week 12, March 19, 2009
Guidelines for Infection Control in Dental Health-Care Settings — 2008
<https://www.cdc.gov/mmwr/PDF/wr12s217.pdf>



Slide 63